


Test Condition: Vibration, Test Mode: GSM, GPRS, Test Band: GSM900, DCS1800

## Test Data


### Clause 4.2.1 Transmitter-Frequency error and phase error

Band	Channel	Frequency (MHz)	PCL	Type	Result	Low Limit	high Limit	Verdict
GSM900	975	880.2	5	Frequency Error (Hz)	-0.81	-88.02	88.02	PASS
GSM900	975	880.2	5	RMS Phase Error (Degree)	0.61	0	5	PASS
GSM900	975	880.2	5	Peak Phase Error (Degree)	1.97	0	20	PASS
GSM900	60	902	5	Frequency Error (Hz)	-9.59	-90.2	90.2	PASS
GSM900	60	902	5	RMS Phase Error (Degree)	0.71	0	5	PASS
GSM900	60	902	5	Peak Phase Error (Degree)	2.20	0	20	PASS
GSM900	124	914.8	5	Frequency Error (Hz)	-14.21	-91.48	91.48	PASS
GSM900	124	914.8	5	RMS Phase Error (Degree)	0.73	0	5	PASS
GSM900	124	914.8	5	Peak Phase Error (Degree)	2.32	0	20	PASS
DCS1800	512	1710.2	0	Frequency Error (Hz)	-6.84	-171.02	171.02	PASS
DCS1800	512	1710.2	0	RMS Phase Error (Degree)	0.82	0	5	PASS
DCS1800	512	1710.2	0	Peak Phase Error (Degree)	2.45	0	20	PASS
DCS1800	700	1747.8	0	Frequency Error (Hz)	-5.97	-174.78	174.78	PASS
DCS1800	700	1747.8	0	RMS Phase Error (Degree)	0.72	0	5	PASS
DCS1800	700	1747.8	0	Peak Phase Error (Degree)	2.20	0	20	PASS
DCS1800	885	1784.8	0	Frequency Error (Hz)	3.71	-178.48	178.48	PASS
DCS1800	885	1784.8	0	RMS Phase Error (Degree)	0.76	0	5	PASS
DCS1800	885	1784.8	0	Peak Phase Error (Degree)	2.32	0	20	PASS


GSM900 Channel=124 PCL=5.png




GSM900 Channel=60 PCL=5.png




GSM900 Channel=975 PCL=5.png




DCS1800 Channel=512 PCL=0.png



DCS1800 Channel=700 PCL=0.png




DCS1800 Channel=885 PCL=0.png




## Clause 4.2.4 Frequency error and phase error in GPRS multi slot configuration

Band	Channel	Frequency (MHz)	Gamma	Type	Result	Low Limit	high Limit	Verdict
GSM900	975	880.2	3;3;3;3	Frequency Error (Hz)	-7.78	-88.02	88.02	PASS
GSM900	975	880.2	3;3;3;3	RMS Phase Error (Degree)	0.58	0	5	PASS
GSM900	975	880.2	3;3;3;3	Peak Phase Error (Degree)	1.75	0	20	PASS
GSM900	60	902	3;3;3;3	Frequency Error (Hz)	-10.69	-90.2	90.2	PASS
GSM900	60	902	3;3;3;3	RMS Phase Error (Degree)	0.66	0	5	PASS
GSM900	60	902	3;3;3;3	Peak Phase Error (Degree)	2.02	0	20	PASS
GSM900	124	914.8	3;3;3;3	Frequency Error (Hz)	-7.39	-91.48	91.48	PASS
GSM900	124	914.8	3;3;3;3	RMS Phase Error (Degree)	0.69	0	5	PASS
GSM900	124	914.8	3;3;3;3	Peak Phase Error (Degree)	2.12	0	20	PASS
DCS1800	512	1710.2	3;3;3;3	Frequency Error (Hz)	3.13	-171.02	171.02	PASS
DCS1800	512	1710.2	3;3;3;3	RMS Phase Error (Degree)	0.84	0	5	PASS
DCS1800	512	1710.2	3;3;3;3	Peak Phase Error (Degree)	2.55	0	20	PASS
DCS1800	700	1747.8	3;3;3;3	Frequency Error (Hz)	6.55	-174.78	174.78	PASS
DCS1800	700	1747.8	3;3;3;3	RMS Phase Error (Degree)	0.71	0	5	PASS
DCS1800	700	1747.8	3;3;3;3	Peak Phase Error (Degree)	2.15	0	20	PASS
DCS1800	885	1784.8	3;3;3;3	Frequency Error (Hz)	-3.58	-178.48	178.48	PASS
DCS1800	885	1784.8	3;3;3;3	RMS Phase Error (Degree)	0.76	0	5	PASS
DCS1800	885	1784.8	3;3;3;3	Peak Phase Error (Degree)	2.37	0	20	PASS


GSM900 Channel=124 Gamma=3;3;3;3.png




GSM900 Channel=60 Gamma=3;3;3;3.png




GSM900 Channel=975 Gamma=3;3;3;3.png



DCS1800 Channel=512 Gamma=3;3;3;3.png



DCS1800 Channel=700 Gamma=3;3;3;3.png



DCS1800 Channel=885 Gamma=3;3;3;3.png

